

Part Number	Description
P1112	- Industrial Air Fed Visor, inc. acetate visor, belt, regulator and disposable Visors (TM 14 7.25)
P1112	- Crusader AIR FED VISOR, as above plus disposable hood, 'rectus' fitting on breathing air hose, power take off for spray gun, adjustable regulator, warning whistle, BSEN 1835 approved. (Polycarbonate visor available for the above units upon request or as a spare part)
P1112-A-002	Regulator inc. nipple (modified to suit industrial unit).
P1112-E-002	Variable flow filter regulator, with belt, in yellow housing.
P1112-A-003	Breathing air hose and silencer.
P1112-B-003	Breathing air hose and silencer (with rectus fitting).
P1112-A-004	Disposable visors pack of 20.
P1112-B-004	Bronze tinted disposable visor (pack of 5).
P1112-A-005	Browguard (excludes comfort band).
P1112-A-006	Filter Visor (P.C.) with air supply tube.
P1112-B-006	Filter Visor (P.C.) with air supply tube (with rectus fitting).
P1112-A-007	Filter Visor (A.C.) with air supply tube.
P1112-B-007	Filter Visor (A.C.) with air supply tube (with rectus fitting).
P1112-B-012	Comfort band for browguard (breathable fabric).
P1112-A-013	Red tailored hood.
P1112-B-013	White disposable hood (5 per pack).
P1112-E-014	Replacement element for P1112-E-002.
P1112-A-015	Spray hose attachment with Rectus fitting and nipple.
P1112-B-016	Draw string bag with logo for storage of Air Fed Visor.
P1112-C-016	Tailored holdall for storage of Air Fed Visor single zip.
P1112 -A - 017	Belt to suit P1112-E-002
P1016-A-005	Belt inc. regulator bracket. 1016-A-020 Air flow meter (For checking air flow prior to use).